



Instant Pop Up Canopy Side Wall Instructions

1



After you have attached the cover to your instant canopy frame and it is locked in the fully extended position your side walls can be attached.

2



Before raising the canopy to an extended height fold up the two adjacent corners of the cover to reveal the inside perimeter hook & loop. Keeping all four walls zipped together, start at one leg and work around the perimeter.

3



Align the wall panels with the sewn seams centered to the length of the legs. Holding the sidewall with the zipper facing out, fold the top edge of the wall so that the hook & loop matches the top edge of the cover.

4



Pull down on each plastic tab (located on the corners of the cover) to turn the exposed edge of the cover and sidewall in. *This could be a tight fit as the cover is brand new. For additional room, unlock the corner fittings to relax the tension & pull the cover valance down. Be sure to re-lock all fittings.* Next secure the hook & loop strips around each corresponding leg. Zipper the ends of each wall together to enclose the canopy.

5



Finish Extending the Legs of the Canopy to Desired Height. Your side wall kit comes equipped with zippered walls for easy entry and exit.

Please Visit Our Website & YouTube Page to View Videos of This and Our Other Setup Instructions for Our Products.